



USER AND SAFETY MANUAL

ROTOR INTERFERENCE DETECTION RID 3.0

Part number 22464112

Version 1.1.0

Date December 18, 2025

CONTENT

| | |
|---|-----------|
| 1. Revisions | 4 |
| 2. List of abbreviations | 5 |
| 3. Preface | 6 |
| 4. Introduction | 7 |
| 4.1. Technical specifications | 7 |
| 5. Safety precautions | 8 |
| 6. Product overview | 9 |
| 6.1. Relay output connections | 9 |
| 6.2. Analog output, input and power supply connections | 10 |
| 6.3. Front connections | 10 |
| 7. Mounting | 11 |
| 8. Installation | 12 |
| 8.1. Electrical installation | 13 |
| 8.2. Ethernet/IP connection | 14 |
| 9. Operation | 15 |
| 9.1. Start up | 15 |
| 9.2. Setup | 15 |
| 9.2.1. Setting the USB connection | 15 |
| 9.2.2. Setting the Ethernet/IP™ connection | 15 |
| 9.2.3. Setting in Rockwell PLC | 16 |
| 9.2.4. Custom Ethernet/IP™ connection | 17 |
| 9.3. Configuration | 17 |
| 9.3.1. Wire calibration | 17 |
| 9.3.2. RID configuration | 18 |
| 9.4. Buttons | 21 |
| 9.5. Indicators | 21 |
| 9.5.1. Meaning of indicator symbols | 22 |
| 9.5.2. Operations Indicators | 22 |
| 9.5.3. Network Indicators | 23 |
| 9.5.4. Ethernet connector Indicators | 24 |
| 9.6. Data logging via the service tool | 24 |
| Appendix A. Ethernet/IP Definitions | 26 |
| Appendix A.1. Parameter definition | 26 |
| Appendix A.1.1. Parameter description | 26 |
| Appendix A.1.2. Parameter values | 27 |

| | |
|--|-----------|
| Appendix A.1.3. Alarm byte definition | 28 |
| Appendix A.2. Connection definition | 28 |
| Appendix A.3. Assembly definition | 29 |
| Appendix B. Revision 1.1.0 change log | 31 |

1. REVISIONS

| | | |
|--------|---|------------|
| V1.0.0 | Initial document | 3-11-2023 |
| V1.0.1 | Added supplier (Page 4), added extra mounting instructions (Page 5), added ventilation requirements (Page 5), added warning in case of misuse of the RID (page 5), added over voltage category (page 4) | 19-11-2023 |
| V1.0.2 | Changed over voltage category (page 4) | 29-11-2023 |
| V1.0.3 | Removed concept from document | 19-02-2024 |
| V1.0.4 | Adjusted for CSA certification | 30-01-2025 |
| V1.0.5 | Adjusted for CSA certification | 25-03-2025 |
| V1.0.6 | Adjusted for CSA certification | 23-04-2025 |
| V1.1.0 | See Appendix B for details. | 18-12-2025 |

2. LIST OF ABBREVIATIONS

| ABBREVIATION | SHORT FOR | DESCRIPTION |
|--------------|-------------------------------------|--|
| CIP | Clean-In-Place | A procedure where a system is internally cleaned without major disassembly. |
| | Common Industrial Protocol | A protocol used for industrial automation that is integrated on an ethernet network. |
| CONT | Contamination | Product build-up between the rotor and body. |
| DHCP | Dynamic Host Configuration Protocol | Network management protocol for automatically assigning IP addresses and other parameters to devices connected to a network. |
| DLR | Device Level Ring | Network topology where ethernet devices are connected in a ring. |
| EDS | Electronic Datasheet | Digital file that describes the configuration of a device for plug-and-play integration in an industrial network. |
| ESD | Electrostatic Discharge | A sudden electric current between two objects often caused by static electricity. |
| IOUT | Current Out | Used as pin indication for the 4-20 mA analog output. |
| MS | Module Status | Used as identification of the LED indicating the module status. |
| MTM | Metal-To-Metal | When a direct contact between rotor and body is detected. |
| NS | Network Status | Used as identification of the LED indicating the network status. |
| OL | Open Loop | Indication for when a break in the measuring circuit is detected. |
| P/OL | Power/Open Loop | Used as identification of the LED indicating the power and open loop status of the device. |
| RID | Rotor Interference Detection | A module used for monitoring rotor to body contact by measuring resistance. |
| RST | Reset | Module reset |

3. PREFACE

This user and safety manual applies to the DMN-WESTINGHOUSE Rotor Interference Detector (RID) 3.0, part number 22464112.

Read this information carefully to prevent damage to the module or any harm to persons or objects.

Supplier information:

DMN-WESTINGHOUSE
Gieterij 3
2211 WC Noordwijkerhout
Netherlands
Phone: +31 252 361 800



Figure 1: Overview of the RID 3.0

4. INTRODUCTION

The RID 3.0 is intended to be used for monitoring metal-to-metal contact and contamination in rotating valves. It generates alarms when a metal-to-metal contact or product build-up occurs. Therefore it can help preventing metallic particles or burrs to accidentally enter the conveyed product.

4.1. TECHNICAL SPECIFICATIONS

Table 1 Technical specifications

| | |
|---|--|
| Supply voltage | 24 VDC \pm 10%, Overvoltage category I |
| Power consumption | 150 mA |
| Ambient temperature | -20 °C – 60 °C (-4 °F – 140 °F) |
| Storage temperature | -20 °C – 60 °C (-4 °F – 140 °F) |
| Relative humidity | 30 – 70%, non-condensing |
| Max. altitude | 2000 m |
| Resistance measurement range | 0 Ω – 10 k Ω |
| Accuracy | 0 Ω – 1 k Ω : 10 Ω 1 k Ω – 10 k Ω : 100 Ω |
| Sample rate | 1 kHz |
| USB connection | USB 2.0 via USB-C |
| Network connection | EtherNet/IP™ (Dual port) |
| Analog output (IOUT) | 4-20 mA |
| Relay max. current (OK, OL, MTM, CONT) | 1 A DC |
| Relay max. voltage (OK, OL, MTM, CONT) | 48 VDC |
| Input voltage (RST, CIP) | 24 VDC \pm 10% |
| Absolute max input voltage (RST, CIP) | 48 VDC |
| Sense line voltage (S1, S2) | 3.3 VDC |
| Maximum sense line voltage (S1, S2) | 28 VDC |
| Sense line current (S1, S2) | <5 mA |

5. SAFETY PRECAUTIONS



- The RID 3.0 may only be installed by certified electrical engineers.
- Take the necessary ESD precautions handling and installing the module.
- For ATEX Environments a Zener safety barrier (Pepperl+Fuchs Z960 or Pepperl+Fuchs Z710) must be added to the system.
- The RID 3.0 may only be operated in an indoor situation.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Make sure the electrical power is turned-off before installing the device.

6. PRODUCT OVERVIEW




Figure 2 Product overview

- 1. Relay output connections
- 2. Rail mount
- 3. Power supply, input, and analog output connections
- 4. Ethernet/IP™ ports
- 5. Reset button
- 6. LED indicators
- 7. USB-C port

6.1. RELAY OUTPUT CONNECTIONS

| CONT | | | MTM | | | OL | | | OK | | |
|------|----|---|-----|----|---|----|----|---|----|----|---|
| NO | NC | C | NO | NC | C | NO | NC | C | NO | NC | C |

Figure 3 Relay output connections

- CONT (Contamination detection)
This relay output switches when the measured resistance drops below the contamination threshold for the set duration.

- MTM (Metal to Metal detection)

This relay output switches when the measured resistance drops below the MTM threshold, exceeds the minimum detection time and satisfies the alarm definition. When CIP mode is activated, the CIP incident and alarm definitions are used as alarm criteria.

- OL (Open loop detection)

This relay output switches when there is an interruption in the sensor wiring.

- OK (OK signal)

This relay is always on when the module is operating.

6.2. ANALOG OUTPUT, INPUT AND POWER SUPPLY CONNECTIONS




Figure 4 Analog output, input and power supply connections

- IOUT (Analog output)

This connection outputs an analog 4-20 mA signal proportional to the measured resistance. The range can be adjusted, see chapter 9.3.2. NOTE: the negative side of the 4-20 mA output is connected internally to the negative terminal of the power supply connection. See Figure 8.

- RST (Reset input)

At this optically isolated input a 24 VDC pulse can be applied to reset the module. Minimum duration of the pulse is 100 ms.

- CIP (CIP mode input)

At this optically isolated input a 24 VDC can be applied to activate the Clean-in-Place mode (CIP). The input must be kept high to keep CIP-mode activated.

- SENSE (Sense line input)

At this port the sense lines must be connected, terminated by the resistor box. S1 must be connected to protective ground at the machine side.

- 24VDC (Power supply)

At this port a 24 VDC power supply should be connected.

6.3. FRONT CONNECTIONS

- RJ45 ports 1 and 2

These connections can be used to connect the module to an Ethernet/IP™ network. Connection 2 can be used for a Device Level Ring (DLR) setup.

- USB-C port (USB 2.0)

This port can be used to connect the module to a PC for configuration and monitoring via the service tool.

7. MOUNTING

- The RID 3.0 must be mounted on a DIN rail in accordance with EN 60715.
- The module can be mounted between other modules as long as the ambient temperature limits are satisfied at all times. See chapter 4.1.
- The RID 3.0 module must be entirely inside the enclosing cabinet.
- The RID 3.0 module does not require mechanical ventilation.

8. INSTALLATION

The RID 3.0 consists of two parts:

- The RID module itself.
- The open loop resistor box.
- The open loop resistor box is already mounted on the valve by DMN-WESTINGHOUSE. See Figure 5 for position.




Figure 5 Position resistor box

ATTENTION!



- The RID 3.0 may only be installed by certified electrical engineers.
- Take the necessary ESD precautions handling and installing the module.
- For ATEX Environments a Zener safety barrier (Pepperl+Fuchs Z960 or Pepperl+Fuchs Z710) must be added to the system.
- When using a 1-channel Zener safety barrier (like Pepperl+Fuchs Z710), make sure the protective earth side is connected to S2 of the RID. Failing to do so results in wrong measurements.

8.1. ELECTRICAL INSTALLATION

1. Connect sense lines S1 and S2 to terminal 1 and 2 of the resistor box on the valve. Use wires with a cross sectional area of 0.75 mm² and a maximum length of 20 m.
 - For non-ATEX environments connect according Figure 6.
 - For ATEX environments add a Zener Barrier according Figure 7.
2. Connect the power supply to the 24VDC +/- terminals according Figure 8.
3. Connect the relay outputs (OK, OL, MTM, CONT) according to Figure 8.
4. Connect the analog output (IOUT) according to Figure 8.
5. Connect the inputs (RST, CIP) according to Figure 8.

ATTENTION!



- Wrong connection can result in no Metal-to-Metal alarms.
- Wrong connection can result in false alarms.
- The resistor in the resistor box will efficiently ground any static electrical charge generated by the isolated rotor.

CAUTION!



- Connect output relays to an appropriate control circuit to ensure the correct measures are taken in case of an alarm.
- It is the responsibility of the end user to ensure that a control system is installed in the system.




Figure 6 Sense line diagram non-ATEX

Figure 7 Sense line diagram ATEX




Figure 8 Connection diagram RID module

8.2. ETHERNET/IP CONNECTION

The RID 3.0 module can be configured and monitored via Ethernet/IP™.

1. Connect Port 1 of the ethernet connection (see chapter 6.3) to the Ethernet/IP™ network.
2. Port 2 can be used for Device Level Ring (DLR) and Daisy-Chain network topologies.

9. OPERATION

9.1. START UP

1. Apply power to the 24 VDC terminal on the RID module.
2. The module will automatically start-up and begin measuring.

9.2. SETUP

9.2.1. SETTING THE USB CONNECTION

1. Download the RID Service Tool via <https://support.dmnwestinghouse.com/en/rid-3-0/>.
2. Open the RID Service Tool.
3. Connect the RID module to the PC via the USB-port (see chapter 6.3).
4. When the device is successfully connected, "Device found" is shown in the top status bar (see Figure 9).




Figure 9 RID Service Tool home screen

9.2.2. SETTING THE ETHERNET/IP™ CONNECTION

1. Make sure the RID module is physically connected to the Ethernet/IP™ network.
2. Open a web browser and enter the IP address of the RID module.
3. When the Anybus CompactCom webserver appears (see Figure 10), the RID module is successfully connected to the Ethernet/IP™ network.




Figure 10 Anybus CompactCom Webserver

The RID is configured by default with DHCP enabled. When desired, the IP-address can be configured manually.

1. Open a web browser and enter the current IP-address of the RID module.
2. Within the Anybus CompactCom webserver go to Network -> Configuration -> IP Configuration.
3. Select DHCP: Disabled.
4. Enter a new IP Address.
5. Click "Save settings".




Figure 11 Anybus CompactCom IP Configuration

9.2.3. SETTING IN ROCKWELL PLC

To create the RID module in RSLogix, the EDS-file is required.

1. Download the latest EDS-file via <https://support.dmnwestinghouse.com/en/rid-3-0/>.
2. Start the EDS Hardware Installation tool in RSLogix.
3. Follow the prompts to register a new EDS device.
4. When asked, browse to the location of the downloaded EDS-file and register as single file.

5. Continue until the import is completed.
6. In the I/O configuration tree select "New Module".
7. Select the RID3 adapter and press create.
8. Give the module a name and fill in the IP-address of the device.
9. Press "OK"

When connecting to a Rockwell PLC it is advised to use a static IP-address. Go to chapter 9.2.2 for instructions on how to disable DHCP.

9.2.4. CUSTOM ETHERNET/IP™ CONNECTION

To connect to the module via Ethernet/IP™ without the use of an EDS or for custom environments, use the Ethernet/IP™ definitions in Appendix A.

9.3. CONFIGURATION

9.3.1. WIRE CALIBRATION

Before operation the RID module must be calibrated to eliminate the effect of the resistance on the sense lines.

ATTENTION!



- When a Zener Barrier is used and the wire calibration is not performed, the readings will be off.
- Before performing the calibration, make sure the valve is cleaned, dried and completely free of product.

Calibration via the Reset button (from firmware V1.1.0)

1. Locate the Reset button on the front of the RID module. See chapter 6.
2. Press and hold the button for minimum 5 seconds.
3. When the reset-button is released the yellow LED-indicator (CONT) blinks for approximately 2 seconds.
4. Depending on the calibration result, the green (P/OL) or red (MTM) LED-indicator turns on for 10 seconds.
 - When the green (P/OL) LED-indicator turns on the calibration was successful.
 - When the red (MTM) LED-indicator turns on the calibration has failed, for example when the circuit has a resistance increase of 150 Ω.
5. After 10 seconds all LED-indicators turn on for a short moment and the RID module returns to normal operation.

Calibration via the service tool

1. Connect the RID module to a PC with the RID Service Tool (see chapter 9.2.1).
2. Go to General Settings within the RID Service Tool.
3. Make sure no open-loop alarm is given.
4. Click on the "Calibrate wiring" button.
5. Follow the prompts.
6. Wait till a prompt with "Wiring Calibrated" is shown and click "OK".

7. The RID module is now calibrated for the wiring.

Calibration via the webserver

1. Connect the RID module to the Ethernet/IP™ network according chapter 9.2.2.
2. Within the webserver go to Module -> Parameters.
3. With the arrows on the top of the screen, navigate to the Calibrate_Wiring parameter.
4. Change the value next to the Calibrate_Wiring parameter from 0 to 1.
5. Click the "Set" button.
6. After a few seconds the value will change to 2.
7. With the arrows on the top of the screen, navigate to the "Store" parameter.
8. Change the value from 0 to 1 and click the "Set" button.
9. After a few seconds the value will change to 2.
10. The RID module is now calibrated for the wiring.

9.3.2. RID CONFIGURATION

General settings

The general settings include:

Table 2 General settings

| PARAMETER | UNIT | STANDARD VALUE | DESCRIPTION |
|---------------------------------------|------|----------------|---|
| 4-20mA lower setpoint | [Ω] | 0 | Sets the lower range boundary of the analog output (corresponding to 4 mA). |
| 4-20mA upper setpoint | [Ω] | 1000 | Sets the upper range boundary of the analog output (corresponding to 20 mA). |
| Open loop detection after | [ms] | 5000 | Sets the time of how long an open loop must be detected continuously before the alarm is given. |
| Auto reset alarm after 5 seconds | [-] | Disabled | Sets if the alarm should reset automatically after 5 seconds. |
| Metal to metal alarm pulse time relay | [s] | 0 | Sets the time after which an MTM alarm is reset automatically. (0 = never reset) |
| CIP alarm pulse time relay | [s] | 0 | Sets the time after which a CIP alarm is reset automatically. (0 = never reset) |
| Contamination alarm pulse time relay | [s] | 0 | Sets the time after which a Contamination alarm is reset automatically. (0 = never reset) |

MTM settings

The MTM settings define the threshold for an MTM alarm. They include:

Table 3 MTM settings

| PARAMETER | UNIT | STANDARD VALUE | DESCRIPTION |
|------------------------|------|----------------|---|
| Detection level | [Ω] | 50 | Sets the resistance threshold under which an MTM detection is registered. |
| Minimum detection time | [ms] | 1000 | Sets the minimum time the resistance must be under the detection level before an MTM detection is registered. |
| Number of incidents | [-] | 3 | Sets the minimum amount of MTM detections within a certain time frame for the MTM alarm to be given. |
| Within time | [ms] | 5000 | Sets the time frame for the MTM alarm. This must be either 0 (OFF) or larger than Minimum detection time x Number of incidents. |

CIP settings

The CIP settings also define the threshold for an MTM alarm. However they are only valid when CIP mode is activated. This is useful during a Clean-in-Place procedure.

Table 4 CIP settings

| PARAMETER | UNIT | STANDARD VALUE | DESCRIPTION |
|------------------------|------|----------------|---|
| Detection level | [Ω] | 10 | Sets the resistance threshold under which an MTM detection is registered. |
| Minimum detection time | [ms] | 1000 | Sets the minimum time the resistance must be under the detection level before an MTM detection is registered. |
| Number of incidents | [-] | 3 | Sets the minimum amount of MTM detections within a certain time frame for the MTM alarm to be given. |
| Within time | [ms] | 5000 | Sets the time frame for the MTM alarm. This must be either 0 (OFF) or larger than Minimum detection time x Number of incidents. |
| Activate CIP mode | [-] | Disabled | This enables or disables CIP mode. |

Contamination settings

The contamination settings define the threshold for a contamination alarm. They include:

Table 5 Contamination settings

| PARAMETER | UNIT | STANDARD VALUE | DESCRIPTION |
|------------------|--------------|----------------|---|
| Detection level | [Ω] | 1000 | Sets the resistance threshold under which a contamination alarm is given. |
| Minimum duration | [s] | 60 | Sets the minimum time the resistance must be under the detection level before a contamination alarm is given. |

Changing settings via the service tool

1. Connect the RID module to a PC with the RID Service Tool (see chapter 9.2.1).
2. Navigate to the parameter you want to change via the navigation bar on the left of the Service Tool.
3. Fill in the desired value next to the parameter.
4. Click the "Write to module" button on the top right to save the setting to the RID module.
5. The setting is now saved.

The screenshot shows the 'Metal to metal definition' settings window in the RID Service Tool. At the top right is a 'Write to module' button. The window is divided into three main sections: 'Incident definition', 'Alarm definition', and 'Calculator'. The 'Incident definition' section has two rows: 'Detection level [Ω]' with a value of 50 and 'Minimum detection time [ms]' with a value of 1000. The 'Alarm definition' section has two rows: 'Number of incidents' with a value of 3 and 'Within time [ms]' with a value of 5000. The 'Calculator' section has a link 'Learn more about calculation' and three rows: 'Rotational speed [rpm]' with a value of 20, 'Critical angle [deg]' with a value of 36, and 'Number of revolutions' with a value of 5. To the right of these rows are labels for 'Minimum detection time' and 'Within time', both showing '... ms'. At the bottom are two buttons: 'Calculate' and 'Apply calculated values'.

Figure 12 Example of settings window RID Service Tool

Changing settings via the webserver

1. Connect the RID module to the Ethernet/IP™ network according chapter 9.2.2.
2. Within the webserver go to Module -> Parameters.
3. With the arrows on the top of the screen, navigate to the parameter you want to change.
4. Change the value next to the parameter.
5. Click the "Set" button.
6. The setting is now saved to the RID module.



ATTENTION!

- Take care changing the parameters. Contact DMN-WESTINGHOUSE in case of any doubt.

9.4. BUTTONS

The RID Module has only a reset button, that can only be operated using a small pin. It is located on the front of the module, see item 5 in chapter 6. The button has two functions:

1. A single click resets all the active alarms.
2. Press-and-hold to calibrate for the wiring, see chapter 9.3.1.

9.5. INDICATORS







Figure 13 Front panel RID Module

The RID 3.0 has LED indicators for status monitoring:

- Operations indicators
- P/OL
- CONT
- MTM
- Network indicators
- MS
- NS
- 4 Ethernet connector indicators

9.5.1. MEANIONG OF INDICATOR SYMBOLS





Table 6 Indicator symbol explanation (green is an example, meaning is the same for all indicator colours)

| | | |
|---|---|---|
|  |  |  |
| Indicator is off | Indicator is on steadily | Indicator is blinking |

9.5.2. OPERATIONS INDICATORS

During start up, all operations indicators light up together for a short period of time.









Table 7 Operation indicators

| | | |
|-------------|---|---|
| P/OL |  | <ul style="list-style-type: none"> • Module operating |
| |  | <ul style="list-style-type: none"> • Open loop alarm |
| CONT |  | <ul style="list-style-type: none"> • Contamination alarm |
| MTM |  | <ul style="list-style-type: none"> • MTM alarm |

9.5.3. NETWORK INDICATORS

During start up, both indicators show red and green for a short period of time.









Table 8 Network indicators

| | | |
|-----------|---|--|
| MS |  | <ul style="list-style-type: none"> No power No IP address |
| |  | <ul style="list-style-type: none"> Online, one or more connections established |
| |  | <ul style="list-style-type: none"> Online, no connections established |
| |  | <ul style="list-style-type: none"> Duplicate IP address Fatal error |
| NS |  | <ul style="list-style-type: none"> No power |
| |  | <ul style="list-style-type: none"> Controlled by a scanner in run state Time is synchronized to a grandmaster clock (if CIP sync enabled) |
| |  | <ul style="list-style-type: none"> Not configured Scanner in idle state Time is synchronized to a grandmaster clock (if CIP sync enabled) |
| |  | <ul style="list-style-type: none"> Recoverable fault(s) Module configured, but parameters differ from currently used parameters |

9.5.4. ETHERNET CONNECTOR INDICATORS

These indicators do not light up during startup.

Table 9 Ethernet connector indicators

| | | |
|---|---|-----------------------|
|  |  | No network connection |
|  |  | Link detected 10Mbit |
|  |  | Link detected 100Mbit |
|  |  | Link detected 1Gbit |

9.6. DATA LOGGING VIA THE SERVICE TOOL

The RID module is able to save measurements and alarms for a maximum of 11 days. This data can be extracted via the RID Service Tool.

1. Connect the RID module to a PC with the RID Service Tool (see chapter 9.2.1).
2. Navigate to the "Logger data" menu in the Service tool.
3. Click the "Update selection from RID" button.
4. Set the start and end sliders to set the wanted time frame.
5. Click the "Get logged data from RID" button. The graph window should now show the measurements during the selected time frame.

The data can be exported to a .csv-file.

6. Click the "Save logged data to file" button.
7. Select a destination.
8. Click "Save".

Earlier saved data can also be imported from a .csv-file.

9. Click the "Update selection from file" button.
10. Select the time frame with the sliders.
11. Click "Get logged data from file". The graph window should now show the measurements during the selected time frame.




ATTENTION!

- If power is removed from the module, the log data is lost.

Logger data

Save logged data to file



How to use the data logger

1. Select one of the 'Update Buttons' to retrieve Start and End position of the data.
2. Adjust Start and End slider to select the desired range.
3. Press 'Get logged data from RID or from file'.

Update selection from RID

Update selection from file

Start

17/05/2025 00:05:10

End

28/05/2025 09:41:44

11d 08:59:54

Get logged data from RID

Get logged data from file

Figure 14 Logger data menu Service Tool

APPENDIX A. ETHERNET/IP DEFINITIONS

APPENDIX A.1. PARAMETER DEFINITION

APPENDIX A.1.1. PARAMETER DESCRIPTION

Table 10 Ethernet/IP parameter description

| PARAMETER | NAME | ACCESS | DATA TYPE | DATA SIZE (BYTES) | DESCRIPTION |
|-----------|-------------------------|---------|-----------|-------------------|-----------------------------------|
| Param1 | Sw_Ver_Major | Get | SINT | 1 | Major software version number |
| Param2 | Sw_Ver_Minor | Get | SINT | 1 | Minor software version number |
| Param3 | Sw_Ver_Rev | Get | SINT | 1 | Revision of the software version |
| Param4 | Hw_Ver | Get | SINT | 1 | Hardware version |
| Param5 | MTM_Resistance | Get/Set | INT | 2 | MTM resistance setpoint |
| Param6 | MTM_Detection_Time | Get/Set | INT | 2 | MTM detection time |
| Param7 | MTM_Incidents | Get/Set | INT | 2 | MTM number of incidents allowed |
| Param8 | MTM_Within_Time | Get/Set | INT | 2 | MTM incidents within time |
| Param9 | MTM_Relay_Time | Get/Set | INT | 2 | MTM relay time |
| Param10 | CIP_Resistance | Get/Set | INT | 2 | CIP resistance setpoint |
| Param11 | CIP_Detection_Time | Get/Set | INT | 2 | CIP detection time |
| Param12 | CIP_Incidents | Get/Set | INT | 2 | CIP number of incidents allowed |
| Param13 | CIP_Within_Time | Get/Set | INT | 2 | CIP incidents within time |
| Param14 | CIP_Relay_Time | Get/Set | INT | 2 | CIP relay time |
| Param15 | CONT_Resistance | Get/Set | INT | 2 | Contamination resistance setpoint |
| Param16 | CONT_Detection_Time | Get/Set | INT | 2 | Contamination detection time |
| Param17 | CONT_Relay_Time | Get/Set | INT | 2 | Contamination relay time |
| Param18 | Auto_Reset | Get/Set | BOOL | 1 | Auto reset of module |
| Param19 | Switch_To_Cip | Get/Set | BOOL | 1 | Switch from MTM to CIP |
| Param20 | OL_Detection_Tim | Get/Set | INT | 2 | Open loop detection time |
| Param21 | Current_Range_Lower | Get/Set | INT | 2 | 4-20mA range lower setpoint |
| Param22 | Current_Range_Upper | Get/Set | INT | 2 | 4-20mA range upper setpoint |
| Param23 | Store | Get/Set | INT | 2 | Store settings |
| Param24 | Current_Resistance | Get | INT | 2 | Current resistance measured |
| Param25 | Alarms | Get | WORD | 2 | Alarm bytes |
| Param26 | MTM_Current_Incidents | Get | INT | 2 | MTM current number of incidents |
| Param27 | MTM_Current_Within_Time | Get | INT | 2 | MTM current within time |
| Param28 | CIP_Current_Incidents | Get | INT | 2 | CIP current number of incidents |

| PARAMETER | NAME | ACCESS | DATA TYPE | DATA SIZE (BYTES) | DESCRIPTION |
|-----------|---------------------------|---------|-----------|-------------------|-------------------------------------|
| Param29 | CIP_Current_Within_Time | Get | INT | 2 | CIP current within time |
| Param30 | CONT_Current_Duration | Get | INT | 2 | Contamination current duration |
| Param31 | Reset | Get/Set | INT | 2 | Reset the alarms |
| Param32 | Calibrate_Wiring | Get/Set | INT | 2 | Calibrate wiring |
| Param33 | Calibrate_Offset | Get/Set | INT | 2 | Calibrate offset |
| Param34 | Calibrate_Supply | Get/Set | INT | 2 | Calibrate supply |
| Param35 | Calibration_Values_Supply | Get | INT | 2 | Stored calibration value for supply |
| Param36 | Calibration_Values_Offset | Get | INT | 2 | Stored calibration value for offset |
| Param37 | Calibration_Values_Wiring | Get | INT | 2 | Stored value for wiring and barrier |
| Param38 | RPI range | Get/Set | UDINT | 4 | RPI range |

APPENDIX A.1.2. PARAMETER VALUES

Table 11 Ethernet/IP parameter values

| PARAMETER | NAME | MIN VALUE | MAX VALUE | DEFAULT VALUE | UNIT |
|-----------|---------------------|-----------|-----------|---------------|------|
| Param1 | Sw_Ver_Major | 0 | 127 | 0 | - |
| Param2 | Sw_Ver_Minor | 0 | 127 | 0 | - |
| Param3 | Sw_Ver_Rev | 0 | 127 | 0 | - |
| Param4 | Hw_Ver | 0 | 127 | 0 | - |
| Param5 | MTM_Resistance | 0 | 500 | 50 | ohm |
| Param6 | MTM_Detection_Time | 10 | 5000 | 1000 | ms |
| Param7 | MTM_Incidents | 1 | 20 | 3 | - |
| Param8 | MTM_Within_Time | 0 | 32000 | 5000 | ms |
| Param9 | MTM_Relay_Time | 0 | 1000 | 0 | s |
| Param10 | CIP_Resistance | 0 | 500 | 10 | ohm |
| Param11 | CIP_Detection_Time | 10 | 5000 | 1000 | ms |
| Param12 | CIP_Incidents | 1 | 20 | 3 | - |
| Param13 | CIP_Within_Time | 1000 | 32000 | 5000 | ms |
| Param14 | CIP_Relay_Time | 0 | 1000 | 0 | s |
| Param15 | CONT_Resistance | 100 | 10000 | 1000 | ohm |
| Param16 | CONT_Detection_Time | 1 | 600 | 60 | s |
| Param17 | CONT_Relay_Time | 0 | 1000 | 0 | s |
| Param18 | Auto_Reset | 0 | 1 | 0 | - |
| Param19 | Switch_To_Cip | 0 | 1 | 0 | - |

| PARAMETER | NAME | MIN VALUE | MAX VALUE | DEFAULT VALUE | UNIT |
|-----------|---------------------------|-----------|-----------|---------------|------|
| Param20 | OL_Detection_Tim | 1000 | 10000 | 5000 | ms |
| Param21 | Current_Range_Lower | 0 | 10000 | 0 | ohm |
| Param22 | Current_Range_Upper | 100 | 10000 | 1000 | ohm |
| Param23 | Store | 0 | 1 | 0 | - |
| Param24 | Current_Resistance | 0 | 32767 | 0 | ohm |
| Param25 | Alarms | 0x0000 | 0x7FFF | 0x0000 | - |
| Param26 | MTM_Current_Incidents | 0 | 32767 | 0 | - |
| Param27 | MTM_Current_Within_Time | 0 | 32767 | 0 | ms |
| Param28 | CIP_Current_Incidents | 0 | 32767 | 0 | - |
| Param29 | CIP_Current_Within_Time | 0 | 32767 | 0 | ms |
| Param30 | CONT_Current_Duration | 0 | 32767 | 0 | s |
| Param31 | Reset | 0 | 1 | 0 | - |
| Param32 | Calibrate_Wiring | 0 | 2 | 0 | - |
| Param33 | Calibrate_Offset | 0 | 2 | 0 | - |
| Param34 | Calibrate_Supply | 0 | 2 | 0 | - |
| Param35 | Calibration_Values_Supply | 0 | 32767 | 3300 | mV |
| Param36 | Calibration_Values_Offset | -32768 | 32767 | 0 | mV |
| Param37 | Calibration_Values_Wiring | 0 | 32767 | 0 | ohm |
| Param38 | RPI range | 1000 | 3200000 | 10000 | ms |

APPENDIX A.1.3. ALARM BYTE DEFINITION

The BYTE definition for Param25.

Table 12 Ethernet/IP Param25 BYTE definition

| ALARM BYTE | NAME | DESCRIPTION |
|------------|----------------------|--------------------------------------|
| 0x0000 | Metal_To_Metal_Alarm | Metal-to-Metal alarm |
| 0x0001 | Contamination_Alarm | Contamination alarm |
| 0x0002 | Open_Loop_Alarm | Open loop alarm |
| 0x0003 | Clean_In_Place_Alarm | Metal-to-Metal alarm during CIP mode |
| 0x0004 | Clean_In_Place_Mode | CIP mode active |

APPENDIX A.2. CONNECTION DEFINITION

Table 13 Ethernet/IP connection definition

| CONNECTION | NAME | RPI | O->T SIZE | O->T ASSEMBLY | T->O SIZE | T->O ASSEMBLY |
|-------------|-----------------|---------|-----------|---------------|-----------|---------------|
| Connection1 | Exclusive owner | Param38 | 38 | Assem150 | 54 | Assem100 |

APPENDIX A.3. ASSEMBLY DEFINITION

Table 14 Ethernet/IP assembly definition

| ASSEMBLY | NAME | BYTE OFFSET | DATA SIZE (BYTE) | PARAMETER |
|----------|----------------|-------------|------------------|-----------|
| Assem150 | Consuming Data | 0 | 2 | Param5 |
| | | 2 | 2 | Param6 |
| | | 4 | 2 | Param7 |
| | | 6 | 2 | Param8 |
| | | 8 | 2 | Param9 |
| | | 10 | 2 | Param10 |
| | | 12 | 2 | Param11 |
| | | 14 | 2 | Param12 |
| | | 16 | 2 | Param13 |
| | | 18 | 2 | Param14 |
| | | 20 | 2 | Param15 |
| | | 22 | 2 | Param16 |
| | | 24 | 2 | Param17 |
| | | 26 | 1 | Param18 |
| | | 27 | 1 | Param19 |
| | | 28 | 2 | Param20 |
| | | 30 | 2 | Param21 |
| | | 32 | 2 | Param22 |
| | | 34 | 2 | Param23 |
| | | 36 | 2 | Param31 |
| Assem100 | Producing Data | 0 | 1 | Param1 |
| | | 1 | 1 | Param2 |
| | | 2 | 1 | Param3 |
| | | 3 | 1 | Param4 |
| | | 4 | 2 | Param5 |
| | | 6 | 2 | Param6 |
| | | 8 | 2 | Param7 |
| | | 10 | 2 | Param8 |
| | | 12 | 2 | Param9 |
| | | 14 | 2 | Param10 |
| | | 16 | 2 | Param11 |
| | | 18 | 2 | Param12 |
| | | 20 | 2 | Param13 |
| | | 22 | 2 | Param14 |
| | | 24 | 2 | Param15 |

| ASSEMBLY | NAME | BYTE OFFSET | DATA SIZE (BYTE) | PARAMETER |
|----------|------|----------------|---------------------|-----------|
| | | 26 | 2 | Param16 |
| | | 28 | 2 | Param17 |
| | | 30 | 1 | Param18 |
| | | 31 | 1 | Param19 |
| | | 32 | 2 | Param20 |
| | | 34 | 2 | Param21 |
| | | 36 | 2 | Param22 |
| | | 38 | 2 | Param24 |
| | | 40 | 2 | Param25 |
| | | 42 | 2 | Param26 |
| | | 44 | 2 | Param27 |
| | | 46 | 2 | Param28 |
| | | 48 | 2 | Param29 |
| | | 50 | 2 | Param30 |
| | | 52 | 2 | Param31 |

APPENDIX B. REVISION 1.1.0 CHANGE LOG

Revisions

- Created separate "Revisions" chapter

List of abbreviations

- Created chapter with list of abbreviations

Preface

- No changes

Introduction

- Changed overview from bullet list to table for better readability

Safety precautions

- Added warning icon
- Removed contact details from list
- Added warning for turn-off power during assembly

Product overview

- Chapter added
- Moved overview of connections from chapter "Installation" to this chapter

Mounting

- Changed to bullet list
- Moved from chapter "Installation" and created new chapter "Mounting"

Installation

- Moved overview of connections to chapter 5 "Product overview"
- Added views for positions of the resistor box.
- Added instructions for installation
- Added connection diagram for RID module
- Added attention and caution points
- Rephrased caution point for the single channel Zener safety barrier

Operation

- Added sub-chapter "Start up"
- Added instructions for setup of:
 - USB connection
 - Ethernet/IP connection
 - Rockwell PLC connection
 - Custom Ethernet/IP connection
- Added sub-chapter "Configuration"
- Added instructions for calibration
- Moved settings to sub-chapter "Configuration"
- Changed overview of settings to table and added descriptions
- Added instruction for changing settings
- Added calibrate function to reset button function overview
- Added figure 12

- Changed style of network indicator descriptions with visuals of LEDs and consistent table style
- Added description of the data log function

Appendix A. Ethernet/IP definitions

- Added ethernet/ip definition

Appendix B. Revision 1.1.0 change log

- Added chapter